
Machining Drawing Symbols Chart

*Machining Drawing
Symbols Chart*

*Downloaded from
old.setefer.com by
Precious Conrad*

INTRODUCTION: DECODING THE LANGUAGE OF PRECISION MANUFACTURING

Every machined part begins its life as a concept on a digital screen or a sheet of paper. But between the designer's vision and the finished component lies a critical vocabulary: the language of engineering drawings. At the heart of this language is the **machining drawing symbols chart**, a reference that translates abstract notations into precise instructions for manufacturing. For machinists, quality inspectors, and design engineers, mastering these symbols is not optional—it is the foundation of producing accurate, functional parts. This article explores the essential symbols found on a typical machining drawing symbols chart, explains their meanings, and demonstrates how they drive consistency and quality in modern manufacturing.

Whether you are a seasoned professional or new to the trade, understanding these symbols helps you interpret surface finishes, geometric tolerances, and material removal requirements with confidence. Let us dive into the core elements of this indispensable tool.

WHAT IS A MACHINING DRAWING SYMBOLS CHART?

A **machining drawing symbols chart**

is a visual reference that catalogs the standardized symbols used on technical drawings to communicate machining requirements. These symbols cover everything from surface roughness to geometric controls, eliminating ambiguity. Adhering to international standards such as **ASME Y14.5** (American Society of Mechanical Engineers) or **ISO 1101** (International Organization for Standardization), the chart ensures that a symbol means the same thing whether the drawing is read in Detroit, Dubai, or Dortmund.

The chart typically includes symbols for:

- Surface finish and texture
- Geometric Dimensioning and Tolerancing (GD&T)
- Material removal indicators
- Thread and fastener callouts
- Datum references
- Welding and edge conditions

By providing a quick lookup, the chart helps machinists avoid misinterpretation, reduce scrap, and speed up setup decisions.

COMMON SURFACE FINISH SYMBOLS

Surface Roughness Symbols

One of the most frequently encountered areas on a machining drawing symbols

chart is the section dedicated to surface finish. The basic symbol resembles a check mark with extended legs. Variations indicate whether material removal is required or not. For example:

- **Basic symbol (no bar):** Indicates a surface without specifying removal method.
- **Symbol with a horizontal bar:** Means material removal is required (e.g., machining).
- **Symbol with a circle:** Indicates no material removal is allowed—the surface must be left as-cast or as-forged.

The numerical value placed above the symbol represents the **roughness average (Ra)** in micrometers or microinches. A lower number means a smoother surface. For instance, an Ra of 0.8 μm is typical for a ground shaft, while 3.2 μm might appear on a general milled surface.

Lay and Waviness

The chart also includes symbols for **lay**—the direction of the predominant surface pattern. Common lay symbols include:

- Parallel lay (two parallel lines)
- Perpendicular lay (a T shape)
- Circular lay (a circle with spokes)
- Multidirectional lay (three crossing lines)

Waviness is denoted by a separate symbol (a wavy line with a height value) and indicates the larger-scale periodic undulations on the surface. Understanding these nuances is vital for applications like sealing surfaces or

bearing journals.

GEOMETRIC DIMENSIONING AND TOLERANCING (GD&T) SYMBOLS

The **GD&T symbols chart** is arguably the most important subset of the overall machining drawing symbols chart. These symbols define the allowable variation in form, orientation, location, and runout. Below are the most critical categories:

Form Tolerances

- **Flatness:** A parallelogram symbol. Controls how flat a surface must be.
- **Straightness:** A short horizontal line. For lines or axes.
- **Circularity:** A circle. Ensures a round cross-section.
- **Cylindricity:** A circle between two slanted lines. Combines roundness and straightness along a cylinder.

Orientation Tolerances

- **Angularity:** An angle symbol (a V shape). Controls the angle relative to a datum.
- **Perpendicularity:** A T shape. Ensures a surface or axis is 90° to a datum.
- **Parallelism:** Two parallel slanted lines. Ensures uniform spacing from a datum.

Location

Tolerances

- **Position:** A crosshair symbol inside a circle. The most versatile symbol for locating features like holes.
- **Concentricity:** Two concentric circles. Rarely used today due to measurement difficulty; often replaced by runout.
- **Symmetry:** A horizontal line with two vertical dashes. Ensures mirrored features.

Runout Tolerances

- **Circular runout:** A single arrow pointing to a line. Controls the deviation of a rotating surface at a single cross-section.
- **Total runout:** Two arrows pointing to a line. Controls the entire surface over the full length.

Each GD&T symbol is accompanied by a tolerance value (in millimeters or inches) and, where needed, a **datum reference letter** (e.g., A, B, C) to establish the measurement origin.

MATERIAL REMOVAL AND SURFACE TEXTURE MODIFIERS

Before machining begins, the drawing must clearly indicate which surfaces require cutting. The machining drawing symbols chart includes special modifiers:

- **All-around symbol:** A small circle attached to the symbol's tail indicates the requirement applies to the entire closed contour.
- **Stock allowance:** A number

placed before the roughness value (e.g., 2 3.2) means 2 mm of material should be left for subsequent machining.

- **Removal by machining:** As noted earlier, the horizontal bar on the surface symbol explicitly calls for material removal.

These symbols prevent costly misunderstandings—for example, a casting that is machined on a surface that should have remained as-cast could ruin its structural integrity or increase cost.

THREAD AND FASTENER SYMBOLS

A typical machining drawing symbols chart also includes notations for threaded features. While not always a symbol in the traditional graphic sense, these callouts follow a strict format. For instance:

- **M10 x 1.5 - 6H** indicates a metric coarse thread (10 mm diameter, 1.5 mm pitch) with a 6H internal thread tolerance class.
- **UNC ¾-20** for unified coarse threads.

Symbols may also indicate thread depth, counterbore, countersink, or spotface requirements. A **counterbore symbol** is usually a circle with the letter "C" inside, while a **countersink symbol** resembles a cone. These are essential for fastener clearance and flush assembly.

DATUM FEATURE SYMBOLS

Datum symbols anchor the entire tolerance system. On a machining drawing symbols chart, a datum is shown as a capital letter enclosed in a

square box, attached to a triangular indicator pointing to the feature. Common examples:

- **Datum A** might be a primary plane (e.g., bottom face).
- **Datum B** might be a side surface or hole axis.
- **Datum C** often establishes a secondary or tertiary constraint.

Datum targets (used for irregular shapes) are indicated by a small circle with a cross, placed on the surface at a specific point. Understanding how to read these datum symbols is critical for proper fixturing and inspection setup.

HOW TO READ A MACHINING DRAWING SYMBOLS CHART EFFECTIVELY

A machining drawing symbols chart is only useful if you know how to navigate it. Here are practical steps:

1. **Identify the standard** listed on the drawing title block (e.g., ASME Y14.5-2018). Use the corresponding chart.
2. **Scan for surface finish symbols** first—these often dictate the machining process (grinding, milling, turning).
3. **Locate GD&T symbols** inside feature control frames. Read from left to right: symbol, tolerance value, modifying condition (if any), and datum letters.
4. **Check for material removal modifiers** to ensure you machine only intended areas.
5. **Cross-reference thread callouts** with tooling specifications.
6. **Note any notes or general tolerances** in the drawing's

remarks section—they may override symbols.

Using the chart as a quick reference reduces errors. Many machinists keep a laminated copy in their toolbox or use digital versions on tablets.

COMMON MISTAKES WHEN INTERPRETING SYMBOLS

Even with a comprehensive machining drawing symbols chart, misreads happen. Avoid these pitfalls:

- **Confusing flatness with parallelism:** Flatness controls the surface's own form; parallelism controls orientation to a datum.
- **Ignoring material condition modifiers:** Symbols like □ (maximum material condition) or □ (least material condition) alter inspection criteria significantly.
- **Overlooking the “all-around” symbol:** Without it, a tolerance applies only to one surface.
- **Mixing metric and imperial roughness values:** Always verify the drawing's unit system.
- **Interpreting a surface symbol without a bar as “no machining”:** Actually, it means the process is unspecified, not that machining is prohibited.

A disciplined approach to reading the chart helps avoid these common blunders.

PRACTICAL APPLICATION: FROM DRAWING TO FINISHED PART

Imagine a drawing for a precision motor housing. The machining drawing symbols chart tells you:

- The mounting face must have a flatness of 0.05 mm relative to

Datum A.

- All bolt hole positions are held to a 0.1 mm positional tolerance at maximum material condition.
- The bore requires a surface roughness of Ra 0.4 μm with a circular lay.
- Two tapped holes require M6 x 1 threads with 6H tolerance, countersink depth 90°.

With the chart, you select the appropriate tools: a fly cutter for the flat face, a precision reamer for the bore, a thread mill or tap for the M6 holes, and a

countersink bit with the correct angle. The inspection plan then uses the datum references to set up a coordinate measuring machine (CMM). Without the chart, each of these decisions could become guesswork.

CONCLUSION

A **machining drawing symbols chart** is more than a collection of icons—it is a bridge between design intent and manufactured reality. By mastering the surface finish symbols, GD&T tolerances, material removal indicators, and datum references, professionals